







ISO 9001: 2015



PED 2014/68/EU





Certificate 3.1

Size: DN 15 to 50 (NPS 1/2" to 2")

Ends: Female - Female NPT, Socket Welding

Min Temperature : -29°C **Max Temperature :** +425°C

Max Pressure: 136 Bars (Class 800)

Specifications: Rising rotating stem (OS&Y)

Welded bonnet Standard bore

Materials: Forged carbon steel A105N

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: www.sferaco.fr E-mail: sferaco@sferaco.fr



SPECIFICATIONS:

- Respect the flow direction (indicated by the arrow)
- Standard bore
- Rising rotating stem (OS&Y)
- Welded bonnet
- · Bolted gland pack
- Forged carbon steel A105N
- Full stellite (Trim 5)
- Class 800

USE:

- Petroleum industry, steam, high pressure
- Min and max Temperature Ts: 29°C to + 425°C
- Max Pressure Ps: 136 bars (see graph)


FLOW COEFFICIENT Kvs (M3/h):

DN	15	20	25	32	40	50
NPS	1/2"	3/4"	1"	1"1/4	1"1/2	2"
Kvs (m3/h)	1.3	3.3	5.9	9.5	12.4	21.6

PRESSURE / TEMPERATURE RELATION:

Pressure (bar)	136.2	136.2	136.2	124,1	120,7	116,6	110	100,7	98,6	97,9	92,7	75,9
Temperature (°C)	-29	0	38	93,5	149	204,5	260	315,5	343,5	371	399	425

PRESSURE / TEMPERATURE GRAPH:



Pressure (Bars)

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: $\underline{www.sferaco.fr}$ E-mail: $\underline{sferaco@sferaco.fr}$


Date: 10/18 Rev.02



RANGE:

- Forged globe valve A105N with threaded NPT ends Ref.416 from DN 15 to 50 (NPS 1/2" to 2")
- Forged globe valve A105N with Socket Welding ends Ref.417 from DN 15 to 50 (NPS 1/2" to 2")

MATERIALS:




Item	Designation	Materials
1	Handwheel nut	Carbon steel
2	ID plate	Aluminium
3	Hanwheel	Carbon steel
4	Yoke nut	ASTM A473 type 416
5	Gland nut	ASTM A194 2H
6	Gland flange	ASTM A105
7	Gland stud	UNS S41000
8	Gland	UNS S41000
9	Packing	Graphite
12	Stem	ASTM A276 type 410
13	Bonnet	ASTM A105N
16	Seat	Stellite GR.6'
18	Body	ASTM A105N
19	Disc	ASTM A182 F6a stellite

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: $\underline{www.sferaco.fr}$ E-mail: $\underline{sferaco@sferaco.fr}$



SIZE (in mm):



Ref.	DN (mm)	15	20	25	40	50
	NPS (")	1/2"	3/4"	1"	1"1/2	2"
416/417	Ø D	9	13	17.5	29.5	35
	L	80	90	110	155	170
	H (opened)	148	165	180	248	257
	øν	80	80	110	130	180
416	L1	15	18	19	21	21
417	L2 (SW)	12.7	14.5	16	19	22
	ø sw	21.8	27.2	33.9	48.8	61.2
416/417	Weight (in Kg)	1.5	1.8	3	6.5	9.7

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: $\underline{www.sferaco.fr}$ E-mail: $\underline{sferaco@sferaco.fr}$

STANDARDS:

- Fabrication according to ISO 9001: 2015
- DIRECTIVE 2014/68/EU: CE N° 0036 Risk category III module H
- Certificate 3.1 on request
- Designing according to ISO 15761 and API 602 8th
- Pressure Tests according to API 598, table 6
- Valves approved by the main oil industries (certificates on request)
- ATEX Group II Category 2 G/2D T3 Zone 1 & 21 Zone 2 &22 (optional marking) according to directive 2014/34/EU
- Threaded female NPT ends according to ANSI B1.20.1
- Socket Welding ends according to ISO 15761

ADVICE: Our opinion and our advice are not guaranteed and SFERACO shall not be liable for the consequences of damages. The customer must check the right choice of the products with the real service conditions.

 $Sferaco\ 90\ rue\ du\ Ruisseau\ 38297\ St\ Quentin\ Fallavier\ \ Tel: +33\ (0)\ 474.94.15.90\ Fax: +33\ (0)\ 474.95.62.08\ \ Internet: \\ \underline{www.sferaco.fr}\ E-mail: \underline{sferaco@sferaco.fr}\ Co.fr$



INSTALLATION INSTRUCTIONS

GENERAL GUIDELINES:

- Ensure that the valves to be used are appropriate for the conditions of the installation (type of fluid,pressure and temperature).
- Be sure to have enough valves to be able to isolate the sections of piping as well as the appropriate equipment for maintenance and repair.
- Ensure that the valves to be installed are of correct strength to be able to support the capacity of their usage.
- Installation of all circuits should ensure that their function can be automatically tested on a regular basis (at least two times a year).

INSTALLATION INSTRUCTIONS:

- Before installing the valves, clean and remove any objects from the pipes (in particular bits of sealing and metal) which could obstruct and block the valves.
- Ensure that both connecting pipes either side of the valve (upstream and downstream) are aligned (if they're not,the valves may not work correctly).
- Make sure that the two sections of the pipe (upstream and downstream) match, the valve unit will
 not absorb any gaps. Any distortions in the pipes may affect the thightness of the connection, the
 working of the valve and can even cause a rupture. To be sure, place the kit in position to ensure the
 assembling will work.
- During welding operation, for S.W. types half open the valve and do not exceed 350-400°C
- The theoretical lengths given by ISO/R7 for the tapping are typically longer than required, the length of the thread should be limited, and check that the end of the tube does not press right up to the head of the thread.
- Never use a vice to tighten the fixings of the valve.
- If sections of piping do not have their final support in place, they should be temporarily fixed. This is to avoid unnecessary strain on the valve.
- It may be necessary to screw the packing gland during using according to the type of use.
- Do not use a tool to shut the valve
- Fluids in the valve must not contain solid objects (it could damaged the seat).
- It's recommended to operate the valve (open and close) 1 to 2 times per year

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: www.sferaco.fr E-mail: sferaco@sferaco.fr