



Size: DN 3/8" to 1"

Ends: Male – Male BSP

Min Temperature : - 20°C Max Température : + 180°C Max Pressure : 63 Bars

Specifications: Anti blow-out stem

Locking device Reduced bore

Materials: Stainless steel ASTM A351 CF8M

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: www.sferaco.fr E-mail: sferaco@sferaco.fr



SPECIFICATIONS:


- Reduced bore
- Anti blow-out stem
- PTFE packing
- Locking device
- Solid ball
- 2 pieces type

USE:

- · Chemical and pharmaceutical industries, petrochemical industries, hydraulic installation, compressed air
- Min and max Temperature Ts: -20°C to + 180°C
- Max Pressure Ps: 63 bars up to DN3/4", 50 bars for DN 1" (see graph)

PRESSURE / TEMPERATURE GRAPH (STEAM EXCLUDED) :

PRESSURE



Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: $\underline{www.sferaco.fr}$ E-mail: $\underline{sferaco@sferaco.fr}$

Date: 10/17 Rev. 07



RANGE:



Stainless steel threaded male/male BSP conical ends with red flat steel handle DN 3/8" to DN 1"



Blue handle cover Ref. 9830380 to 9830382 from DN 3/8" to DN 1"




• S.S.304 red butterfly handle **Ref. 9831131 to 9831134** from DN 3/8" to DN 1"

 $Sferaco\ 90\ rue\ du\ Ruisseau\ 38297\ St\ Quentin\ Fallavier\ \ Tel: +33\ (0)\ 474.94.15.90\ Fax: +33\ (0)\ 474.95.62.08\ \ Internet: \\ \underline{www.sferaco.fr}\ E-mail: \underline{sferaco@sferaco.fr}\ Co.fr$



MATERIALS:




Item	Designation	Materials	
1	Body	ASTM A351 CF8M	
2	Ball	ASTM A351 CF8M	
3	Stem	AISI 316	
4	Bonnet	ASTM A351 CF8M	
5	Body seal	PTFE	
6	Seat	PTFE filled with 15% glass fiber	
7	Stem gasket	PTFE	
8	Packing	PTFE	
9	Packing nut	AISI 304	
10	Handle	AISI 304	
11	Handle cover	Plastic	
12	Locking device		
13	Washer	AISI 304	
14	Handle nut		

 $Sferaco\ 90\ rue\ du\ Ruisseau\ 38297\ St\ Quentin\ Fallavier\ \ Tel: +33\ (0)\ 474.94.15.90\ Fax: +33\ (0)\ 474.95.62.08\ \ Internet: \\ \underline{www.sferaco.fr}\ E-mail: \\ \underline{sferaco@sferaco.fr}\ E-mail: \\ \underline{sferaco.fr}\ E-mail: \\ \underline{sfe$



SIZE (in mm):




Ref.	DN	3/8"	1/2"	3/4"	1"
	L	66	76	86	96
	Ød	8.5	12.5	17.5	23.6
	Ø P	12.5	15	20	25
	E	83	103	103	151
709	н	53	60	62	77
	L1	11.2	14.7	16.2	19
	С	5	6.5	6.5	8
	ØΥ	7	7.5	7.5	9
	Weight (Kg)	0.26	0.33	0.51	0.79

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: $\underline{www.sferaco.fr}$ E-mail: $\underline{sferaco@sferaco.fr}$



BUTTERFLY HANDLE SIZE (in mm):





Ref. 983113 :

DN	3/8"	1/2"	3/4"	1"
L	55	60	60	70
н	20	22	22	28
С	5	6.5	6.5	8
Y	8	9.5	9.5	11.5

FLOW COEFFICIENT Kvs (M3/h):

DN	1/2"	3/4"	1"
Kvs (m3/h)	25	50	100

TORQUE VALUES (in Nm without safety coefficient):

DN	3/8"	1/2"	3/4"	1"
Torque (Nm)	2.7	3	4	5

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: $\underline{www.sferaco.fr}$ E-mail: $\underline{sferaco@sferaco.fr}$

Date : 10/17 Rev. 07
Page 6 sur 7



STANDARDS:

- Fabrication according to ISO 9001: 2015
- DIRECTIVE 2014/68/EU: CE N° 0035 Risk category III Module H
- Certificate 3.1 on request
- Pressure tests according to ISO 5208, rate A
- Threaded male conical ends BSP according to ISO 7/1 R

ADVICE: Our opinion and our advice are not guaranteed and SFERACO shall not be liable for the consequences of damages. The customer must check the right choice of the products with the real service conditions.

INSTALLATION AND MAINTENANCE

BEFORE INSTALLATION:

Pipe-line must be cleaned and free from residual of weldings,rubbish,shaving and every kind of extraneous materials. Pipe-line must be perfectly aligned and their support properly dimensioned so that there's no external constraint.

Please use the right product according to the services conditions to seal the valve. Use the right bolt tightening so that the ends won't be damaged.

CLEANING AND TESTS

Keep opened the valves during the cleaning operation so that there are no impurities between the ball and the body.

Tests under pressure must be done with a cleaned pipe-line.

Open partially the valve for tests. Pressure test do not exceed the valve specifications according to EN 12266-1.

MAINTENANCE

It's recommended to operate the valve twice (open and close) 1 to 2 times per year.

When intervention on the valve, be sure there's no pressure in the pipe-line, there's no fluid in it, and that it is isolated. The temperature must be low enough to operate without risks. If there's a corrosive fluid, inert installation before intervention.

When the valve is under pressure:

If there's a leakage at the packing, tighten it slightly so that the leakage disappears.

Sferaco 90 rue du Ruisseau 38297 St Quentin Fallavier Tel: + 33 (0) 474.94.15.90 Fax: + 33 (0) 474.95.62.08 Internet: www.sferaco.fr E-mail: sferaco@sferaco.fr